



### INSTALLATION INSTRUCTIONS

1. DIG FOOTING AT PROPER LOCATION 24" WIDE x 54" DEEP.
2. PLACE SLEEVE INTO FOOTING AND SUPPORT IN A PLUMB CONDITION WITH THE OUTSIDE EDGE OF THE PIPE TANGENT TO THE OUTSIDE OF THE FOUL LINE. ROTATE THE POST SO THAT THE PANELS ARE TO THE INSIDE OF THE FIELD.
3. REPEAT FOR OTHER FOUL LINE.

3/4" RE-BAR x 46", 6 PLACES PER FOOTING (NOT INCLUDED, TO BE PROVIDED BY INSTALLER). THESE ARE TYPICAL FOOTING DIMENSIONS FOR AVERAGE SOIL CONDITIONS.

# Jaypro Sports

976 Hartford Turnpike  
 Waterford, CT 06385 USA  
 (800)243-0533  
 (800)988-3363 Fax  
 www.jaypro.com

MODEL NO.:  
**BBCFP-20 Sleeve**

PRODUCT NAME:  
**FPS-20**

DRAWN BY:  
 MT

EFFECTIVE DATE:  
 3-7-12