

Write Way® Directional Sign



Dual-sided dry-erase board can be positioned to point people in the right direction. Simply write your message on the attention-getting arrow-shaped surface and position the sign up, down, left or right. Change your message as often as needed. The dual-sided dry-erase board is ideal for use with magnets and allows viewing from either side. Arrow adjusts + or - 45°. 18" wide base can be weighted with water or sand for stability. Molded construction with UV inhibitors for indoor or outdoor use. Black finish. Easy assembly required.

Model	Description	W x D x H	Ship Weight	Price Each
4173BL	Write Way Directional Sign	25½ x 17¾ x 64¼"	10 lbs.	\$123.00

Discount Code B

