


VCTR47-VCTR42-LCTR47-LCTR42-INSTRUCTIONS

You will need 2 person(s) for this assembly.

You will need a Phillips Head Screw Driver and a Rubber Mallet to Assemble.

Hardware :

A: Corner Bracket(4) • B: Small Screws(24) • C: Cam Pins(4) • D: Cam Covers(4)



Parts :


E: Leg A • F: Leg B • G: Top




fig. 1a



STEP 1 : Place 4 cam pins(C) in bottom of table top(G).



STEP 2 : Lay table top(G) down cam pins facing up and attach leg B(F) by inserting cam pins(C) into locks and tightening.(See Fig. 1a)




IMPORTANT NOTICE:

- Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Do not tighten all screws/bolts until completely assembled.
- Keep all hardware parts out of reach of children.

VCTR47-VCTR42-LCTR47-LCTR42- INSTRUCTIONS

**You will need 2 person(s) for this assembly.
You will need a Phillips Head Screwdriver and a Rubber Mallet to Assemble.**

STEP 4 : Attach leg A(E) by inserting cam pins(C) into locks and tightening. (See Fig. 1a)



STEP 5 : Attach 4 brackets(A) to the bottom of the top(G) and legs for support *one per leg*. Use 6 screws(B) for each bracket(A).



To finish table cover cam lock holes with cam lock caps(D).

