
SDLStage Dolly

Assembly Instructions

Tools Required

Cresent (adjustable)Wrench





Loading Stages:

- National Public SEATING Corp.
- 149 ENTIN ROAD, CLIFTON, NJ 07014
 TEL 973-594-1100 | FAX 973-594-1500
 e-mail: info@NationalPublicSeating.com
- 1) For 48" wide stages, screw the top cross bar in the upper holes. For 36" wide stages screw the top cross bar into the lower holes.
- 2) Once dolly is assembled, rotate latch and load stages. Release latch into original position to prevent stages from falling off the dolly.