

## Intuitive Frame (IT Leg)



**Step 1:**  
Place  
crossbar  
over C-  
bracket



**Step 2:** Line up holes  
and screw fasteners to  
top and bottom of each  
side of frame.

## All-terrain (AT Leg ) Skip Step 1&2



**Step 3:** Align slots on legs with metal  
insert holes in tops and tighten  
screws. Flip over table and enjoy  
years of use.

## Adjusting Height

Remove  
Set-  
Screw  
with Hex  
Tool



Slide  
Out  
Leg  
Lower



Take  
off  
Bezel



Place  
Bezel at  
Desired  
Height  
&  
Replace  
Set-  
Screw



## Height Settings

it leg top height	23.5"	24.5"	25.5"	26.5	27.5"	28.5"	29.5"	30.5"	31.5"	32.5"	33.5"	34.5"
AT leg top height	24.5"	25.5"	26.5	27.5"	28.5"	29.5"	30.5"	31.5"	32.5"	33.5"	34.5"	35.5"
# of holes showing	0	1	2	3	4	5	6	7	8	9	10	11