



# Instructions for HWT C3713

Call 1-866-816-9822 with any questions.



1 02 pcs



2 01 pc

Hardware list



A x 01 pc




B x 01 pc




C x 04 pcs



D x 12 pcs



Step 1



Step 2