










**IMPORTANT NOTICE:
HARDWARE PACKAGE IS ATTACHED
ON THE BOTTOM OF SEAT CUSHION.**

MODEL : B7719 B709

| | | |
|--|---|---|
| (1)x1 | (2)x1 | (3)x1 (L)x1 (R) |
|  |  |  |
| Back | Seat | Right Frame & Left Frame |
| (4)x1 | (5)x2 | |
|  |  | |
| Connecting Bar | | |
| (A)x4 |  | M6*40 SEAT SCREW |
| (B)x4 |  | M6*25 BACK SCREW |
| (C)x2 |  | M6*14 CONNECTING BAR SCREW |
| | | (Please find these 2 screws on sled base.) |



Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.

