

Assembly Instructions


Table/Leg Assembly

(Adjustable & Non-Adjustable Legs)

For: Models: 4000 & Zuma Series

1. Place the table top on a clean, level surface with its bottom side up.
2. Align the leg attaching brackets with corner pilot holes as shown, and attach to the underside of the top with #10 screws, using a power screwdriver. * Install the remaining screws into each bracket at this point.
3. Repeat steps 1-2 for the remaining leg assemblies. NOTE: For tables with adjustable legs, leg height can be adjusted by loosening the leg's set screw with the Allen wrench provided, as shown. Once the leg is readjusted to the desired height, make sure the set screw is fully seated in its adjustment hole, then tighten firmly. Repeat this process with other leg assemblies so that all are adjusted to the same height.




* Use caution not to over tighten as this may strip threads.



The following parts are included with each model(s):

Qty.	Description
4	Leg Assembly
4	Lower Leg Tube
4	Set Screw 3/8-16
36	Screw PPH #10

Required Assembly Tools:

	Phillips Head Screwdriver
	Allen Wrench 3/16" (Provided)
	Power Screwdriver



VIRCO MFG.
CORPORATION
TORRANCE, CA.

TITLE
Assembly Instructions
Table/Leg Assembly
(Adjustable & Non-Adjustable Legs)
For: Models 4000 & Zuma Series

Form No. 2006752

FILE NO.

2006752

DATE

02/24/2004

REV.

F

ECA NO. 2003-157