







Visionary™ Boards







2' X 3', 3' X 4', 4' X 4', 4' X 6' and 4' X 8'



Assembly Instructions

Visionary™ Board

Part	Drawing	Description	Qty	Part	Drawing	Description	Qty
P-1		Glass Board	1 EA				
P-2		Tray Mount	1 EA				
P-3		Aluminum Tray	1 EA				

Hardware List			
A		Outer Cap	See Chart
B		Wall Mount	See Chart
C		Plastic Anchor	See Chart
D		CS Screw	See Chart
E		Drywall Anchor	See Chart
F		Phillips Tray Screw	See Chart

Hardware Chart by Model # & Board Size	
83843	2'X3' GBoard - 4 pcs. (A), (B) 6 pcs. (C), (D), (E) 2 pcs. (F)
83844	3'X4' GBoard - 4 pcs. (A), (B) 6 pcs. (C), (D), (E) 2 pcs. (F)
83847	4'X4' PJWBoard - 4 pcs. (A), (B) 6 pcs. (C), (D), (E) 2 pcs. (F)
83845	4'X6' GBoard - 6 pcs. (A), (B) 8 pcs. (C), (D), (E) 2 pcs. (F)
83846	4'X8' GBoard - 8 pcs. (A), (B) 10 pcs. (C), (D), (E) 2 pcs. (F)
83849	4'X4' PJGBoard- 4 pcs. (A), (B) 6 pcs. (C), (D), (E) 2 pcs. (F)
83848	4'X6' PJWBoard- 6 pcs. (A), (B) 8 pcs. (C), (D), (E) 2 pcs. (F)
83850	4'X6' PJGBoard-6 pcs. (A), (B) 8 pcs. (C), (D), (E) 2 pcs. (F)

Missing Parts or UPS Damaged Parts
 For Your Convenience you can
 EMAIL us at
support@moorecoinc.com
 24HOURS 7 DAYS A WEEK


*Should you require assistance during assembly,
 please call our
 Customer Service Department
 Monday - Friday 8 a.m. - 5 p.m.
 Central Standard Time
 Toll-Free Customer Service
1-800-749-2258*

Important Information

Do not use unless all screws are tight. At least every six months, check all screws to be sure they are tight. If parts are missing, broken, damaged, or worn, stop use of the product until repairs are made by your dealer using factory authorized parts.

Preparing to Install Your New Visionary™ Board

Measure the length and width of your new board. Determine the wall center line and height off the floor that you want your new board to be located. Hold your board up in position and draw a line 3/8" above the top edge of your board and 3/8" below the bottom edge of your board. If your wall has studs, determine the centerline of the studs. It is recommended that you tie into as many studs as possible when mounting your board.




Typical Room With Stud Wall Centered Board Layout

NOTE: The proper installation of your board will require at least two people.
Tools required: Tape measure, chalkline, electric drill / screwdriver, drill and screwdriver bits, stud finder and level.

Installing the Aluminum Marker Tray

- 1.) Install the Aluminum Marker Tray to the wall before you install your Visionary Board.
- 2.) Determine where you want your tray to be located and mark a line 1" above the bottom edge of your board. Drill two 5/16" diameter holes in the wall 5 3/4" apart.



- 3.) Push in two Plastic Anchors (C) into the predrilled holes. Place the Tray Mount (P-2) over the Plastic Anchors (C) and secure with two CS Screws (D) as shown in Illustration #1.
- 4.) Place the Aluminum Tray (P-3) in the front slot of the Tray Mount (P-2) and align the holes. Secure the Aluminum Tray (P-3) to the Tray Mount (P-2) using two Phillips Tray Screws (F). See Illustration #2.





Illustration #2

To Assemble and Attach to Wall:


- 1.) Identify and Separate all the Parts and Hardware.
- 2.) After you have followed the guidelines from the previous page, install the correct number of Board Mounts (B) for the size board you are mounting to the wall. Install the Board Mounts as shown in Illustration #1 and Illustration #1a.
- 3.) For all walls except sheet rock:

Pre-drill a 5/16" diameter hole on the line that was drawn 3/8" below and 3/8" above the top and bottom edges of your new board. Push in a Plastic Anchor (C) into the pre-drilled hole. Place the bottom hole in the Wall Mount (B) on top of the Plastic Anchor (C) and attach using one CS Screw (D). Repeat this Step for each Wall Mount that is required for your size board.




- 3a.) For sheet rock walls:

Screw in a Drywall Anchor (F) on the line that was drawn 3/8" below and 3/8" above the top and bottom edges of your new board. Place the bottom hole in the Wall Mount (B) on top of the Drywall Anchor (F) and attach using one CS Screw (D). Repeat this Step for each Wall Mount that is required for your size board.



- 4.) Your attached Wall Mounts (B) should be turned as shown in Illustration #2.



- 5.) Place the Glass Board (P1) between and resting on the step ledge on each Wall Mount (B). Secure the Glass Board (P1) in place by screwing in a Top Cap (A) into each treaded hole in the Wall Mounts (B) as shown in Illustration #3

