


PLEASE NOTE:
 1) FOR SAFE OPERATION AND CONTINUED HIGH PERFORMANCE FROM THIS EQUIPMENT, INSPECTION AND MAINTENANCE MUST BE PERFORMED BEFORE EACH USE

2) USE OF THIS EQUIPMENT OTHER THAN INTENDED, MAY BE HAZARDOUS.

3) ALTERATION OR MODIFICATION OF EQUIPMENT MAY BE HAZARDOUS. FOR REPAIR OR REPLACEMENT, PLEASE CALL YOUR DEALER



PUSH THREADED INSERT APPROX
 1/2" INTO EACH END OF ALL
 CROSSBARS

| | |
|--|---|
| <p>JAYPRO SPORTS, LLC 976 HARTFORD TURNPIKE WATERFORD, CT 06385 USA (800)243-0533 (800)988-3363 FAX WWW.JAYPRO.COM</p> | |
| <p>MODEL NO.: BBC-12/BBC-18</p> | <p>PRODUCT NAME: BASKETBALL CARRIER</p> |
| <p>DRAWN BY: JAC</p> | <p>EFFECTIVE DATE: 4-3-03</p> |

JAYPRO SPORTS
BASKETBALL CARRIER, BBC-12/BBC-18
LIST OF MATERIALS

| <u>PIECE NO.</u> | <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QTY.</u> |
|------------------|-----------------|------------------------------|-------------|
| 1 | BBC821 | SIDE FRAME | 2 |
| 2 | HS2650 | HEX HEAD SCREW 5/16"-18 x 1" | 10 |
| 3 | HW2083 | FLAT WASHER 5/16" | 10 |
| 4 | HM5060 | THREADED INSERT 5/16"-18 | 10 |
| 5 | BBC125 | CROSSBAR 38" FOR BBC-12 | 5 |
| 6 | CS0009 | CASTER | 4 |
| 7 | CS0010 | CASTER INSERT | 4 |
| 8 | BBC185 | CROSSBAR 57 1/2" FOR BBC-18 | 5 |

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED: 1/2" BOX WRENCH OR ADJUSTABLE WRENCH

- 1) Push one threaded insert (4) approximately 1/2" into each of all the crossbars (5 or 8). Note that the inserts are slightly concave. This allows the insert to push into the crossbar but not pull out. For best results, thread one of the 5/16"-18 x 1" hex head screws (2) into the concave side of the insert, place it over the end of the crossbar (5 or 8) and gently tap the head of the screw until the insert is seated at the proper depth. Remove the screw and the insert will hold its position.
- 2) Position plastic inserts (7) into bottom of side frame tubing. Gently drive into place.
- 3) Assemble the lower middle crossbar (5 or 8) to the two side frames (1) as shown in the illustration. Assemble the remaining hardware loosely to the ends of the remaining crossbars (5 or 8) and set these into the slots on each side frame (1). Tighten all hardware.
- 4) Assemble the casters (6) into the bottom of each side frame (1) as shown.